


09 20 62 031



| | | |
|---|---------------------------------|-----------------|
|  | Chrom | 09 20 62 031-00 |
|  | chrom gebürstet (04) | 09 20 62 031-04 |
|  | Platin gebürstet | 09 20 62 031-06 |
|  | Dark Chrome | 09 20 62 031-19 |
|  | Light Gold | 09 20 62 031-26 |
|  | Light Gold gebürstet | 09 20 62 031-27 |
|  | Schwarz matt | 09 20 62 031-33 |
|  | Dark Brass gebürstet | 09 20 62 031-39 |
|  | Bronze gebürstet | 09 20 62 031-42 |
|  | Champagne gebürstet (22kt Gold) | 09 20 62 031-46 |
|  | Champagne (22kt Gold) | 09 20 62 031-47 |
|  | Chrom gebürstet | 09 20 62 031-93 |
|  | Dark Platinum gebürstet | 09 20 62 031-99 |



Zugknopf Ø 45 x 10 mm - Chrom

ERSATZTEILE

09 20 62 031



Zugknopf Ø 45 x 10 mm - Chrom

ERSATZTEILE

09 20 62 031