












04 20 36 100 02



	Platin	04 20 36 100 02-08
	Chrom	04 20 36 100 02-00
	Platin gebürstet	04 20 36 100 02-06
	Messing (23kt Gold)	04 20 36 100 02-09
	Dark Brass matt	04 20 36 100 02-16
	Dark Bronze matt	04 20 36 100 02-17
	Messing gebürstet (23kt Gold)	04 20 36 100 02-28
	Dark Brass gebürstet	04 20 36 100 02-39
	Bronze gebürstet	04 20 36 100 02-42
	Dark Platinum gebürstet	04 20 36 100 02-99



Griff Neutral 57 x 57 x 34 mm - Platin

ERSATZTEILE

04 20 36 100 02



Griff Neutral 57 x 57 x 34 mm - Platin

ERSATZTEILE

04 20 36 100 02