



















09 20 36 030



	Messing (23kt Gold)	09 20 36 030-09
	Chrom	09 20 36 030-00
	Gold (23,9kt)	09 20 36 030-01
	bronze	09 20 36 030-02
	altmessing	09 20 36 030-03
	chrom gebürstet (04)	09 20 36 030-04
	Platin gebürstet	09 20 36 030-06
	Platin	09 20 36 030-08
	weiß	09 20 36 030-12
	Dark Brass matt	09 20 36 030-16
	Dark Bronze matt	09 20 36 030-17
	Messing gebürstet (23kt Gold)	09 20 36 030-28
	Dark Brass gebürstet	09 20 36 030-39
	chrom satin	09 20 36 030-41
	Bronze gebürstet	09 20 36 030-42
	Champagne (22kt Gold)	09 20 36 030-47
	Dark Platinum gebürstet	09 20 36 030-99



Zugknopf Ø 30 x 27 mm - Messing (23kt Gold)

ERSATZTEILE

09 20 36 030



Zugknopf Ø 30 x 27 mm - Messing (23kt Gold)

ERSATZTEILE

09 20 36 030