





















09 20 88 040



	Platin	09 20 88 040-08
	Chrom	09 20 88 040-00
	Platin gebürstet	09 20 88 040-06
	Messing (23kt Gold)	09 20 88 040-09
	Weiß matt	09 20 88 040-10
	Dark Brass matt	09 20 88 040-16
	Dark Bronze matt	09 20 88 040-17
	Dark Chrome	09 20 88 040-19
	Light Gold gebürstet	09 20 88 040-27
	Messing gebürstet (23kt Gold)	09 20 88 040-28
	Schwarz matt	09 20 88 040-33
	Dark Brass gebürstet	09 20 88 040-39
	Bronze gebürstet	09 20 88 040-42
	aluminium (45)	09 20 88 040-45
	Champagne gebürstet (22kt Gold)	09 20 88 040-46
	Champagne (22kt Gold)	09 20 88 040-47
	Cyprum	09 20 88 040-49
	Chrom gebürstet	09 20 88 040-93
	Dark Platinum gebürstet	09 20 88 040-99



Griff Hebel Ø 43 x 29 mm - Platin

ERSATZTEILE

09 20 88 040



Griff Hebel Ø 43 x 29 mm - Platin

ERSATZTEILE

09 20 88 040