




















09 20 71 002



	Dark Platinum gebürstet	09 20 71 002-99
	Chrom	09 20 71 002-00
	Platin gebürstet	09 20 71 002-06
	Platin	09 20 71 002-08
	Weiß matt	09 20 71 002-10
	Dark Brass matt	09 20 71 002-16
	Dark Bronze matt	09 20 71 002-17
	Dark Chrome	09 20 71 002-19
	Light Gold	09 20 71 002-26
	Light Gold gebürstet	09 20 71 002-27
	Messing gebürstet (23kt Gold)	09 20 71 002-28
	Schwarz matt	09 20 71 002-33
	Dark Brass gebürstet	09 20 71 002-39
	Bronze gebürstet	09 20 71 002-42
	Champagne gebürstet (22kt Gold)	09 20 71 002-46
	Champagne (22kt Gold)	09 20 71 002-47
	Cyprum	09 20 71 002-49
	Chrom gebürstet	09 20 71 002-93



Griff Ø 32 x 36 mm - Dark Platinum gebürstet

ERSATZTEILE

09 20 71 002



Griff Ø 32 x 36 mm - Dark Platinum gebürstet

ERSATZTEILE

09 20 71 002