




90 30 30 061 00



	Messing (23kt Gold)	90 30 30 061 00-09
	Chrom	90 30 30 061 00-00
	Gold (23,9kt)	90 30 30 061 00-01
	chrom gebürstet (04)	90 30 30 061 00-04
	chrom edelmatt	90 30 30 061 00-05
	Platin gebürstet	90 30 30 061 00-06
	Platin	90 30 30 061 00-08
	weiß	90 30 30 061 00-12
	schwarz	90 30 30 061 00-13
	Gold gebürstet (23,9kt)	90 30 30 061 00-14
	rot (15)	90 30 30 061 00-15
	Messing gebürstet (23kt Gold)	90 30 30 061 00-28
	Rot	90 30 30 061 00-29
	Schwarz matt	90 30 30 061 00-33
	nachtblau	90 30 30 061 00-34
	Platin / Platin gebürstet	90 30 30 061 00-36
	chrom satin	90 30 30 061 00-41
	cyprum matt	90 30 30 061 00-56
	schwarz glänzend	90 30 30 061 00-76



Schraube - Messing (23kt Gold)

ERSATZTEILE

90 30 30 061 00



Schraube - Messing (23kt Gold)

ERSATZTEILE

90 30 30 061 00