










04 12 11 098 00



	Platin	04 12 11 098 00-08
	Chrom	04 12 11 098 00-00
	Platin gebürstet	04 12 11 098 00-06
	Messing gebürstet (23kt Gold)	04 12 11 098 00-28
	Champagne gebürstet (22kt Gold)	04 12 11 098 00-46
	Champagne (22kt Gold)	04 12 11 098 00-47
	Chrom gebürstet	04 12 11 098 00-93
	Dark Platin gebürstet	04 12 11 098 00-99



## Spülbrause 170 x 50 x 45 mm - Platin

ERSATZTEILE

---

04 12 11 098 00



Spülbrause 170 x 50 x 45 mm - Platin

ERSATZTEILE

04 12 11 098 00

04 12 11 098 00

Ersatzteile für die  
anderen  
Oberflächenvarianten  
finden Sie hier:  
Chrom

