












04 20 36 100 01



| | | |
|---|----------------------------------|--------------------|
|  | Messing gebürstet (23kt Gold) | 04 20 36 100 01-28 |
|  | Chrom | 04 20 36 100 01-00 |
|  | Platin gebürstet | 04 20 36 100 01-06 |
|  | Platin | 04 20 36 100 01-08 |
|  | Messing (23kt Gold) | 04 20 36 100 01-09 |
|  | Dark Brass matt | 04 20 36 100 01-16 |
|  | Dark Bronze matt | 04 20 36 100 01-17 |
|  | Dark Brass gebürstet | 04 20 36 100 01-39 |
|  | Bronze gebürstet | 04 20 36 100 01-42 |
|  | Dark Platin gebürstet | 04 20 36 100 01-99 |



Griff Hot 57 x 57 x 34 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

04 20 36 100 01



Griff Hot 57 x 57 x 34 mm - Messing gebürstet (23kt Gold)

ERSATZTEILE

04 20 36 100 01