





















04 24 04 287 00



	Platin	04 24 04 287 00-08
	Chrom	04 24 04 287 00-00
	chrom gebürstet (04)	04 24 04 287 00-04
	Platin gebürstet	04 24 04 287 00-06
	Messing (23kt Gold)	04 24 04 287 00-09
	Weiß matt	04 24 04 287 00-10
	schwarz	04 24 04 287 00-13
	Dark Brass matt	04 24 04 287 00-16
	Dark Bronze matt	04 24 04 287 00-17
	Dark Chrome	04 24 04 287 00-19
	Light Gold gebürstet	04 24 04 287 00-27
	Messing gebürstet (23kt Gold)	04 24 04 287 00-28
	Schwarz matt	04 24 04 287 00-33
	Dark Brass gebürstet	04 24 04 287 00-39
	Bronze gebürstet	04 24 04 287 00-42
	Champagne gebürstet (22kt Gold)	04 24 04 287 00-46
	Champagne (22kt Gold)	04 24 04 287 00-47
	Cyprum	04 24 04 287 00-49
	Chrom gebürstet	04 24 04 287 00-93
	Dark Platinum gebürstet	04 24 04 287 00-99



Nippel 20° Ø 26 mm - Platin

ERSATZTEILE

04 24 04 287 00



Nippel 20° Ø 26 mm - Platin

ERSATZTEILE

04 24 04 287 00