

09 20 78 032



	Chrom	09 20 78 032-00
	Platin gebürstet	09 20 78 032-06
	Platin	09 20 78 032-08
	Dark Brass matt	09 20 78 032-16
	Dark Bronze matt	09 20 78 032-17
	Dark Chrome	09 20 78 032-19
	Light Gold gebürstet	09 20 78 032-27
	Messing gebürstet (23kt Gold)	09 20 78 032-28
	Bronze gebürstet	09 20 78 032-42
	Champagne gebürstet (22kt Gold)	09 20 78 032-46
	Champagne (22kt Gold)	09 20 78 032-47
	Cyprum	09 20 78 032-49
	Dark Platin gebürstet	09 20 78 032-99



Zugknopf 6 x 15 x 30 mm - Chrom

ERSATZTEILE

09 20 78 032



Zugknopf 6 x 15 x 30 mm - Chrom

ERSATZTEILE

09 20 78 032