















Zugstange für Umstellung Ø 12 x 46 mm - Chrom

ERSATZTEILE

09 31 09 094 20



	Chrom	09 31 09 094 20-00
	Platin gebürstet	09 31 09 094 20-06
	Platin	09 31 09 094 20-08
	Weiß matt	09 31 09 094 20-10
	Dark Chrome	09 31 09 094 20-19
	Light Gold gebürstet	09 31 09 094 20-27
	Messing gebürstet (23kt Gold)	09 31 09 094 20-28
	Schwarz matt	09 31 09 094 20-33
	Dark Brass gebürstet	09 31 09 094 20-39
	chrom satin	09 31 09 094 20-41
	Bronze gebürstet	09 31 09 094 20-42
	Champagne gebürstet (22kt Gold)	09 31 09 094 20-46
	Champagne (22kt Gold)	09 31 09 094 20-47
	Dark Platinum gebürstet	09 31 09 094 20-99



Zugstange für Umstellung Ø 12 x 46 mm - Chrom

ERSATZTEILE

09 31 09 094 20



## Zugstange für Umstellung Ø 12 x 46 mm - Chrom

ERSATZTEILE

09 31 09 094 20