

















90 20 97 507 00



	Weiß matt	90 20 97 507 00-10
	Chrom	90 20 97 507 00-00
	chrom gebürstet (04)	90 20 97 507 00-04
	Platin gebürstet	90 20 97 507 00-06
	Platin	90 20 97 507 00-08
	Dark Brass matt	90 20 97 507 00-16
	Dark Bronze matt	90 20 97 507 00-17
	Dark Chrome	90 20 97 507 00-19
	Light Gold	90 20 97 507 00-26
	Light Gold gebürstet	90 20 97 507 00-27
	Messing gebürstet (23kt Gold)	90 20 97 507 00-28
	Schwarz matt	90 20 97 507 00-33
	Dark Brass gebürstet	90 20 97 507 00-39
	Bronze gebürstet	90 20 97 507 00-42
	Champagne gebürstet (22kt Gold)	90 20 97 507 00-46
	Champagne (22kt Gold)	90 20 97 507 00-47
	Cyprum	90 20 97 507 00-49
	Chrom gebürstet	90 20 97 507 00-93
	Dark Platinum gebürstet	90 20 97 507 00-99



Bürstengriff - Weiß matt

ERSATZTEILE

90 20 97 507 00



Bürstengriff - Weiß matt

ERSATZTEILE

90 20 97 507 00

90 20 97 507 00

Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier:
Chrom

