

04 20 78 030 80



|   |                                 |                    |
|---|---------------------------------|--------------------|
|    | Platin gebürstet                | 04 20 78 030 80-06 |
|    | Chrom                           | 04 20 78 030 80-00 |
|    | Platin                          | 04 20 78 030 80-08 |
|    | Messing (23kt Gold)             | 04 20 78 030 80-09 |
|    | Dark Brass matt                 | 04 20 78 030 80-16 |
|    | Dark Bronze matt                | 04 20 78 030 80-17 |
|    | Light Gold gebürstet            | 04 20 78 030 80-27 |
|    | Messing gebürstet (23kt Gold)   | 04 20 78 030 80-28 |
|    | Schwarz matt                    | 04 20 78 030 80-33 |
|   | Dark Brass gebürstet            | 04 20 78 030 80-39 |
|  | Bronze gebürstet                | 04 20 78 030 80-42 |
|  | Champagne gebürstet (22kt Gold) | 04 20 78 030 80-46 |
|  | Champagne (22kt Gold)           | 04 20 78 030 80-47 |
|  | Cyprum                          | 04 20 78 030 80-49 |
|  | Chrom gebürstet                 | 04 20 78 030 80-93 |
|  | Dark Platin gebürstet           | 04 20 78 030 80-99 |



Zugstange für Ablaufgarnitur mit Knopf 18 x 83 x 18 mm - Platin gebürstet

ERSATZTEILE

04 20 78 030 80



Zugstange für Ablaufgarnitur mit Knopf 18 x 83 x 18 mm - Platin gebürstet

ERSATZTEILE

04 20 78 030 80