


















09 11 02 537



	Messing (23kt Gold)	09 11 02 537-09
	Chrom	09 11 02 537-00
	chrom gebürstet (04)	09 11 02 537-04
	Platin gebürstet	09 11 02 537-06
	Platin	09 11 02 537-08
	Weiß matt	09 11 02 537-10
	Dark Brass matt	09 11 02 537-16
	Dark Bronze matt	09 11 02 537-17
	Dark Chrome	09 11 02 537-19
	Light Gold	09 11 02 537-26
	Light Gold gebürstet	09 11 02 537-27
	Messing gebürstet (23kt Gold)	09 11 02 537-28
	Schwarz matt	09 11 02 537-33
	Dark Brass gebürstet	09 11 02 537-39
	chrom satin	09 11 02 537-41
	Bronze gebürstet	09 11 02 537-42
	Champagne gebürstet (22kt Gold)	09 11 02 537-46
	Champagne (22kt Gold)	09 11 02 537-47
	Cyprum	09 11 02 537-49
	Chrom gebürstet	09 11 02 537-93
	Dark Platinum gebürstet	09 11 02 537-99



xTOOL Rosette Ø 124 x 10 mm - Messing (23kt Gold)

ERSATZTEILE

09 11 02 537



xTOOL Rosette Ø 124 x 10 mm - Messing (23kt Gold)

ERSATZTEILE

09 11 02 537